

Prop Sox[®]


INSTRUCTIONS

PROP SOX[®] Propeller Covers

Prop Sox are protection for propellers and people. They guard your expensive propellers from road kickback when towing. Curious children will be discouraged from spinning your propeller while the boat is out of the water. People walking by a boat on a trailer won't be cut with Prop Sox in place. Prevent rear-end accidents when towing by alerting drivers following too closely.

Prop Sox are made of bright, molded plastic and simply slip over each propeller blade. The sox are held in place with a rubber shock cord strap. Set of three socks, strap and 3 reflector hot-dots included. For use when your boat is out of the water only.

Patented.



Installs in Seconds:



1. Put rubber cinch strap over the hub of the propeller and slip blade covers onto propeller blades with each reflective dot facing out.



2. Secure blade covers with the rubber cinch strap stretched onto all three locking tabs. This holds the blade covers securely together for trailering.



3. The propeller is now protected and the sharp edges are covered, reducing the chance of injury from curious children or people running into the exposed blades.

Never operate the motor with Prop Sox in place.

Davis Instruments

3465 Diablo Ave., Hayward, CA 94545 U.S.A.
Phone (510) 732-9229 • Fax (510) 732-9188
info@davisnet.com www.davisnet.com